

Is your home **WILDFIRE PREPARED?**

ROOF:

- Choose a Class A fire-rated roof maintained clear of debris.
- Choose noncombustible gutters and downspouts.

ADDITIONAL MITIGATION:

- Remove back-to-back fencing.
- Eliminate combustible siding.
- Enclose eaves, cover gutters.
- Enclose under-bay windows.
- Upgrade to a wildfire-resistant deck.
- Upgrade windows and doors.
- Move outbuildings at least 30 feet away.

DEFENSIBLE SPACE:

- Within 15 feet of a structure remove all conifers and dry or dead vegetation.
- Clear and maintain the underdeck area; enclose low-elevation decks.
- Maintain yard clear of debris.
- Replace combustible fencing within five feet of the house.

HOUSE FEATURES:

- Ember- and flame-resistant vents.
- Six-inch vertical noncombustible clearance at base of wall.

For detailed risk mitigation strategies, review the Alaska Firewise booklet:
<https://forestry.alaska.gov/Assets/pdfs/home/firewise09.pdf>

Presented By:
Alaska Division of Insurance